


# IXIZSTRUCTIONS



## CONTACT

Email: [ixizconcept@gmail.com](mailto:ixizconcept@gmail.com)

Tel: 678.871.8861 Fax: 206.202.0847

## Honda Civic 8<sup>th</sup> Gen - Hood Lift

### Features:



- Installs in less than 5 minutes with basic tools.
- Increases the work area under the hood and remove the stock post impediment
- **No drilling nor rivetting.**
- Hardware are all anodized Alum. and **stainless steel.** (Guaranteed Rust Free)
- Secure custom CNC brackets will not shift during usage.
- Opening motion is smooth, effortless and precise.
- Design for stock or carbon hoods
- Fits both Coupe and Sedan

## PACKING LIST

Hood Damper (w/ 2 swivels and hardware), Upper-Bracket and Lower-Bracket  
Verify all components are present – 3 components total



Hardware included are all stainless and brackets are all anodized aluminum

Ixizstructions : Install instructions and supplemental video online available  
Video: [http://www.ixizconcept.com/Honda/ixizhood/civic\\_ixizhood\\_install.MPG](http://www.ixizconcept.com/Honda/ixizhood/civic_ixizhood_install.MPG)  
(caution 48MB filesize)

**Tools Required**

- 10 mm wrench
- 3/8" wrench (design feature – because wrench sets normally have metric and standard sets) & requires 2 wrenches for installation
- Bolt fastener [Loctite] (optional)

**Lower section of the damper (has the smaller diameter) goes onto the front of the car**

1. Insert lower swivel bolt onto lower bracket and fasten the 6mm bolt (self locking)



(picture above shows the bracket in silver for visibility / illustration only)

**Install Lower Bracket**

1. Loosen the front bolt [FB] on the vehicle (expose about 2mm of threaded section) not required to fully remove from base.
2. Remove the backing tape (optional) – Double sided tape on the lower bracket



3. Slide the Lower bracket assembly with strut installed onto the bolt. There is a step on the bracket for the bracket to stop on the edge of the car. Press the bracket towards the base if backing tape is used.

**The lower bracket assembly is now complete**

### Install Upper Bracket

1. Loosen both the upper hinge bolts. Remove the lower bolt [A] and attach the upper bracket but not completely tightening the Bolt [A], allowing the bracket to rotate
  - Additional assistance may be required – The design of the ixizhood increases the work area under the hood by opening the hood further for better access. Assistance is required to hold the hood in place while installing the strut onto the bracket



(picture above shows the bracket in silver for visibility / illustration only)

2. Insert upper swivel bolt onto upper bracket and fasten the 6mm bolt (self locking).
3. Remove the upper bolt [B] and rotate the bracket in place and reinsert the hinge bolt [B]. With both the hinge bolts [A]+[B] in place and the hood damper attached to the upper bracket. Tighten both the hinge bolts and secure the damper bolt.

**The upper bracket assembly is now complete**

### IXIZHOOD INITIAL CLOSING AND SETTING

First time usage

1. Make sure all tools are removed from engine bay
2. Check all brackets are mounted securely and verify the position (see pictures above).
3. Check all hardware is mounted securely
4. CLOSE the Hood slowly to lubricate the internals of the damper and reopen the hood slowly.

**YOUR IXIZHOOD IS NOW FULLY ASSEMBLED**

Please post a review at your favorite forums. Ixizconcept does not advertise and depends on its supporters for promotion. The best way to thank us is to write a review of your experience and quality of service.

**Thank you**